

## Pin assignment

Pin assignment number: 1800

Connector name: 26-pol CONTACT

Index:

Pin-count: 26

13.01.2021

Page: 1/1

| Pin | Designation               | Description                    | Colour |
|-----|---------------------------|--------------------------------|--------|
| 1   | PNT_Adress+_IN            | Data input +                   | -      |
| 2   | PNT_Adress-_IN            | Data input -                   | -      |
| 3   | PNT_Data+_OUT             | Data output +                  | -      |
| 4   | PNT_Data-_OUT             | Data output -                  | -      |
| 5   | Baud 2 <sup>0</sup> _IN   | Baud rate 2 <sup>0</sup>       | -      |
| 6   | Baud 2 <sup>1</sup> _IN   | Baud rate 2 <sup>1</sup>       | -      |
| 7   | Adress 2 <sup>0</sup> _IN | Encoder address 2 <sup>0</sup> | -      |
| 8   | Adress 2 <sup>1</sup> _IN | Encoder address 2 <sup>1</sup> | -      |
| 9   | not connected             |                                | -      |
| 10  | Preset1_IN                | Preset value 1                 | -      |
| 11  | Preset2_IN                | Preset value 2                 | -      |
| 12  | CH_A_OUT                  | Channel A                      | -      |
| 13  | CH_B_OUT                  | Channel B                      | -      |
| 14  | not connected             |                                | -      |
| 15  | not connected             |                                | -      |
| 16  | not connected             |                                | -      |
| 17  | not connected             |                                | -      |
| 18  | not connected             |                                | -      |
| 19  | not connected             |                                | -      |
| 20  | not connected             |                                | -      |
| 21  | not connected             |                                | -      |
| 22  | not connected             |                                | -      |
| 23  | not connected             |                                | -      |
| 24  | Supply Voltage IN         | Supply voltage                 | -      |
| 25  | Ground IN                 | Ground                         | -      |
| 26  | not connected             |                                | -      |

|                    |                  |        |       |       |      |
|--------------------|------------------|--------|-------|-------|------|
| <b>BAUD RATE :</b> | '                | 307200 | 38400 | 19200 | 9600 |
|                    | 2 <sup>0</sup> : | NC     | US    | NC    | US   |
|                    | 2 <sup>1</sup> : | NC     | NC    | US    | US   |
|                    | 2 <sup>2</sup> : | NC     | NC    | NC    | NC   |
|                    | 2 <sup>3</sup> : | NC     | NC    | NC    | NC   |
|                    | '                |        |       |       |      |

### WARNING

'De-energize the system before carrying out wiring work or opening and closing electrical connections !

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.