

Pin assignment

Pin assignment number: 3885

Index:

13.01.2021

Connector name: M23 12-pol

Pin-count: 12

Page: 1/1

| Pin | Designation | Description | Colour |
|-----|---------------------|----------------------------------|--------|
| 1 | CH_A_OUT | Channel A | - |
| 2 | /CH_A_OUT | Channel A inverted | - |
| 3 | Overspeed_OUT | Overspeed | - |
| 4 | CH_B_OUT | Channel B | - |
| 5 | /CH_B_OUT | Channel B inverted | - |
| 6 | Set CH_I_IN | | - |
| 7 | CH_I_OUT | Channel Reference | - |
| 8 | /CH_I_OUT | Channel Reference inverted | - |
| 9 | Ser.Program+_IN/OUT | Ser. programming interface RS485 | - |
| 10 | Ser.Program-_IN/OUT | Ser. programming interface RS485 | - |
| 11 | Supply Voltage IN | Supply voltage | - |
| 12 | Ground IN | Ground | - |

WARNING

'De-energize the system before carrying out wiring work or opening and closing electrical connections !

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.