

Pin assignment

Pin assignment number: 4122

Connector name: 37-pol SUB-D

Index:

Pin-count: 37

13.01.2021

Page: 1/2

Pin	Designation	Description	Colour
1	O_D0	Data output	-
2	O_D1	Data output	-
3	O_D2	Data output	-
4	O_D3	Data output	-
5	O_D4	Data output	-
6	O_D5	Data output	-
7	O_D6	Data output	-
8	O_D7	Data output	-
9	O_D8	Data output	-
10	O_D9	Data output	-
11	O_D10	Data output	-
12	O_D11	Data output	-
13	not connected		-
14	not connected		-
15	not connected		-
16	not connected		-
17	not connected		-
18	not connected		-
19	not connected		-
20	not connected		-
21	not connected		-
22	Parity dynamically	Parity Even	-
23	not connected		-
24	not connected		-
25	not connected		-
26	not connected		-
27	not connected		-
28	not connected		-
29	not connected		-
30	not connected		-
31	Direction IN	Change of counting direction	-
32	Supply Voltage IN	Supply voltage	-
33	Ground IN	Ground	-
34	not connected		-
35	Supply Voltage IN	Supply voltage	-
36	not connected		-
37	Supply Voltage IN	Supply voltage	-

Pin assignment

Pin assignment number: 4122

Connector name: 37-pol SUB-D

Index:

Pin-count: 37

13.01.2021

Page: 2/2

WARNING

'De-energize the system before carrying out wiring work or opening and closing electrical connections !

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.