

## Pin assignment

Pin assignment number: 527

Connector name: 37-pol SUB-D

Index:

Pin-count: 37

13.01.2021

Page: 1/2

Pin	Designation	Description	Colour
1	Program_Enable_IN	High=Progr.-Enable	-
2	DATA+_OUT	Data output	-
3	DATA-_OUT	Data output	-
4	not connected		-
5	not connected		-
6	DATA-_OUT	Data output	-
7	DATA+_OUT	Data output	-
8	Program_Enable_IN	High=Progr.-Enable	-
9	Preset1_IN	Preset value 1	-
10	not connected		-
11	Supply Voltage IN	Supply voltage	-
12	Ground IN	Ground	-
13	not connected		-
14	not connected		-
15	not connected		-
16	not connected		-
17	not connected		-
18	not connected		-
19	not connected		-
20	not connected		-
21	not connected		-
22	not connected		-
23	not connected		-
24	not connected		-
25	not connected		-
26	not connected		-
27	not connected		-
28	not connected		-
29	not connected		-
30	not connected		-
31	not connected		-
32	not connected		-
33	not connected		-
34	not connected		-
35	not connected		-
36	not connected		-
37	not connected		-

## Pin assignment

Pin assignment number: 527

Connector name: 37-pol SUB-D

Index:

Pin-count: 37

13.01.2021

Page: 2/2

### **WARNING**

'De-energize the system before carrying out wiring work or opening and closing electrical connections !

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.