

# Pin assignment

Pin assignment number: 1946

Index: + 1454A = K135

14.07.2011

Connector name: 12-pol.CONTACT Pin-count: 12

Page: 1/1

Pin	Designation	Description	Level	Driver	NC	Color
1	CH_A_OUT	Channel A	RS 422	RS 422		white
2	/CH_A_OUT	Channel A inverted	RS 422	RS 422		brown
3	CH_B_OUT	Channel B	RS 422	RS 422		green
4	/CH_B_OUT	Channel B inverted	RS 422	RS 422		yellow
5	Softendswitch_OUT1	Data output	Supply Voltage	Push Pull		gray
6	Softendswitch_OUT2	Data output	Supply Voltage	Push Pull		pink
7	Softendswitch_OUT3	Data output	Supply Voltage	Push Pull		blue
8	Softendswitch_OUT4	Data output	Supply Voltage	Push Pull		red
9	Stop_OUT	High=STOP	Supply Voltage	Push Pull		black
10	Preset1_IN	Preset value 1	Supply Voltage		0	violet
11	Supply Voltage IN	Supply voltage	11-27V			gray/pink
12	Ground IN	Ground	0V			red/blue

## Connector coding

!!! Connector Y - coded !!!

## WARNING !!

\*\*\*\*\*

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!  
Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.

# Pin assignment

Pin assignment number: 1454

Index: A + 1946 = K135

14.07.2011

Connector name: 12-pol.CONTACT Pin-count: 12

Page: 1/1

Pin	Designation	Description	Level	Driver	NC	Color
1	SSI_Clock-_IN	Clock input -	RS 422	RS 422		white
2	SSI_Clock+_IN	Clock input +	RS 422	RS 422		brown
3	SSI_DATA+_OUT	Data output +	RS 422	RS 422		green
4	SSI_DATA-_OUT	Data output -	RS 422	RS 422		yellow
5	Ser.Program+_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		gray
6	Ser.Program-_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		pink
7	not connected					
8	not connected					
9	not connected					
10	not connected					
11	Supply Voltage IN	Supply voltage	11-27V			gray/pink
12	Ground IN	Ground	0V			red/blue

**WARNING !!**

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!  
Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.