

Pin assignment

Pin assignment number: 179

Index: + 3858 = K340

13.09.2011

Connector name: 25-pol.SUB-D

Pin-count: 25

Page: 1/1

Pin	Designation	Description	Level	Driver	NC	Colour
1	O_D0	Data output				white
2	O_D1	Data output				brown
3	O_D2	Data output				green
4	O_D3	Data output				yellow
5	O_D4	Data output				gray
6	O_D5	Data output				pink
7	O_D6	Data output				blue
8	O_D7	Data output				red
9	O_D8	Data output				black
10	O_D9	Data output				violet
11	O_D10	Data output				gray/pink
12	O_D11	Data output				red/blue
13	O_D12	Data output				white/green
14	O_D13	Data output				brown/green
15	O_D14	Data output				white/yellow
16	O_D15	Data output				yellow/brown
17	O_D16	Data output				white/gray
18	O_D17	Data output				gray/brown
19	Preset1_IN	Preset value 1	Supply Voltage		0	white/pink
20	not connected					
21	Direction IN	Change of counting direction	Supply Voltage		0	white/blue
22	Ser.Program+_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		brown/blue
23	Ser.Program-_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		white/red
24	Supply Voltage IN	Supply voltage	11-27V			brown/red
25	Ground IN	Ground	0V			white/black

WARNING !!

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.

Pin assignment

Pin assignment number: 3858
Index: + 179 = K340

13.09.2011

Connector name: 12-pol.CONTACT
Pin-count: 12

Page: 1/1

Pin	Designation	Description	Level	Driver	NC	Colour
1	SSI_Clock-_IN	Clock input -	RS 422	RS 422		white
2	SSI_Clock+_IN	Clock input +	RS 422	RS 422		brown
3	SSI_DATA+_OUT	Data output +	RS 422	RS 422		green
4	SSI_DATA-_OUT	Data output -	RS 422	RS 422		yellow
5	not connected					
6	not connected					
7	not connected					
8	not connected					
9	Ser.Program+_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		black
10	Ser.Program-_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		violet
11	Supply Voltage IN	Supply voltage	11-27V			gray/pink
12	Ground IN	Ground	0V			red/blue

WARNING !!

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!
 Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.