

Pin assignment

Pin assignment number: 760
Index: + 1160 = K95

12.07.2011

Connector name: 15-pol.SUB-D
Pin-count: 15

Page: 1/1

Pin	Designation	Description	Level	Driver	NC	Color
1	Ser.Program-_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		
2	Ser.Program-_IN/OUT	Ser. programming interface RS485	RS 485	RS 485		
3	not connected					
4	not connected					
5	not connected					
6	not connected					
7	not connected					
8	not connected					
9	not connected					
10	not connected					
11	not connected					
12	not connected					
13	not connected					
14	Supply Voltage IN	Supply voltage	11-27V			
15	Ground IN	Ground	0V			

WARNING !!

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.

Pin assignment

Pin assignment number: 1160

Index: + 760 = K95

12.07.2011

Connector name: 26-pol.CONTACT Pin-count: 26

Page: 1/1

Pin	Designation	Description	Level	Driver	NC	Color
1	O_D0	Data output				white
2	O_D1	Data output				brown
3	O_D2	Data output				green
4	O_D3	Data output				yellow
5	O_D4	Data output				gray
6	O_D5	Data output				pink
7	O_D6	Data output				blue
8	O_D7	Data output				red
9	O_D8	Data output				black
10	O_D9	Data output				violet
11	O_D10	Data output				gray/pink
12	O_D11	Data output				red/blue
13	O_D12	Data output				withe/green
14	O_D13	Data output				brown/green
15	O_D14	Data output				withe/yellow
16	O_D15	Data output				yellow/brown
17	not connected					
18	not connected					
19	not connected					
20	not connected					
21	not connected					
22	not connected					
23	not connected					
24	Supply Voltage IN	Supply voltage	11-27V			brown/red
25	Ground IN	Ground	0V			withe/black
26	not connected					

WARNING !!

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.