

Pin assignment

Pin assignment number: 1101

Index:

13.01.2021

Connector name: 37-pol SUB-D

Pin-count: 37

Page: 1/2

| Pin | Designation | Description | Colour |
|-----|---------------------|----------------------------------|--------|
| 1 | O_D0 | Data output | - |
| 2 | O_D1 | Data output | - |
| 3 | O_D2 | Data output | - |
| 4 | O_D3 | Data output | - |
| 5 | O_D4 | Data output | - |
| 6 | O_D5 | Data output | - |
| 7 | O_D6 | Data output | - |
| 8 | O_D7 | Data output | - |
| 9 | O_D8 | Data output | - |
| 10 | O_D9 | Data output | - |
| 11 | O_D10 | Data output | - |
| 12 | O_D11 | Data output | - |
| 13 | O_D12 | Data output | - |
| 14 | O_D13 | Data output | - |
| 15 | O_D14 | Data output | - |
| 16 | O_D15 | Data output | - |
| 17 | O_D16 | Data output | - |
| 18 | O_D17 | Data output | - |
| 19 | O_D18 | Data output | - |
| 20 | O_D19 | Data output | - |
| 21 | O_D20 | Data output | - |
| 22 | O_D21 | Data output | - |
| 23 | O_D22 | Data output | - |
| 24 | O_D23 | Data output | - |
| 25 | DataBus_IN | High=tristate | - |
| 26 | not connected | | - |
| 27 | Preset1_IN | Preset value 1 | - |
| 28 | not connected | | - |
| 29 | I_Latch | High=Latch | - |
| 30 | Direction IN | Change of counting direction | - |
| 31 | not connected | | - |
| 32 | Preset2_IN | Preset value 2 | - |
| 33 | not connected | | - |
| 34 | Ser.Program+_IN/OUT | Ser. programming interface RS485 | - |
| 35 | Ser.Program-_IN/OUT | Ser. programming interface RS485 | - |
| 36 | Supply Voltage IN | Supply voltage | - |
| 37 | Ground IN | Ground | - |

Pin assignment

Pin assignment number: 1101

Connector name: 37-pol SUB-D

Index:

Pin-count: 37

13.01.2021

Page: 2/2

WARNING

'De-energize the system before carrying out wiring work or opening and closing electrical connections !

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.