

## Pin assignment

Pin assignment number: 1357

Index:

13.01.2021

Connector name: with cable outlet

Pin-count: 37

Page: 1/2

Pin	Designation	Description	Colour
1	O_D0	Data output	white
2	O_D1	Data output	brown
3	O_D2	Data output	green
4	O_D3	Data output	yellow
5	O_D4	Data output	gray
6	O_D5	Data output	pink
7	O_D6	Data output	gray/pink
8	O_D7	Data output	red/blue
9	O_D8	Data output	white/green
10	O_D9	Data output	brown/green
11	O_D10	Data output	white/yellow
12	O_D11	Data output	yellow/brown
13	O_D12	Data output	white/gray
14	O_D13	Data output	gray/brown
15	O_D14	Data output	white/pink
16	O_D15	Data output	pink/brown
17	O_D16	Data output	white/blue
18	O_D17	Data output	brown/blue
19	O_D18	Data output	white/red
20	O_D19	Data output	brown/red
21	O_D20	Data output	white/black
22	O_D21	Data output	brown/black
23	O_D22	Data output	gray/green
24	O_D23	Data output	yellow/gray
25	Preset1_IN	Preset value 1	green/blue
26	I_Latch	High=Latch	green/red
27	Direction IN	Preset value 1	yellow/red
28	Preset2_IN	Preset value 2	yellow/black
29	Ser.Program+_IN/OUT	Ser. programming interface RS485	pink/green
30	Ser.Program-_IN/OUT	Ser. programming interface RS485	yellow/pink
31	Supply Voltage IN	Supply voltage	red
32	Ground IN	Ground	blue
33	not connected		
34	not connected		
35	not connected		
36	not connected		
37	not connected		

## Pin assignment

Pin assignment number: 1357

Connector name: with cable outlet

Index:

Pin-count: 37

13.01.2021

Page: 2/2

### **WARNING**

'De-energize the system before carrying out wiring work or opening and closing electrical connections !

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.