

# Pin assignment

Pin assignment number: 898

Connector name: 15-pol HARTING

Index: A

Pin-count: 15

13.01.2021

Page: 1/1

Pin	Designation	Description	Colour
A1	PNT_Adres+_IN	Data input +	-
A2	PNT_Adres-_IN	Data input -	-
A3	PNT_Data+_OUT	Data output +	-
A4	PNT_Data-_OUT	Data output -	-
A5	Adress 2 <sup>3</sup> _IN	Encoder address 2 <sup>3</sup>	-
B1	Baud 2 <sup>0</sup> _IN	Baud rate 2 <sup>0</sup>	-
B2	Baud 2 <sup>1</sup> _IN	Baud rate 2 <sup>1</sup>	-
B3	Adress 2 <sup>1</sup> _IN	Encoder address 2 <sup>1</sup>	-
B4	Heating_IN	Heating +24V	-
B5	Heating_Ground_IN	Heating Ground	-
C1	Preset1_IN	Preset value 1	-
C2	Adress 2 <sup>2</sup> _IN	Encoder address 2 <sup>2</sup>	-
C3	Adress 2 <sup>0</sup> _IN	Encoder address 2 <sup>0</sup>	-
C4	Supply Voltage IN	Supply voltage	-
C5	Ground IN	Ground	-

<b>BAUD RATE :</b>	'	307200	38400	19200	9600
	2 <sup>0</sup> :	NC	US	NC	US
	2 <sup>1</sup> :	NC	NC	US	US
	2 <sup>2</sup> :	NC	NC	NC	NC
	2 <sup>3</sup> :	NC	NC	NC	NC
	'				

## WARNING

'De-energize the system before carrying out wiring work or opening and closing electrical connections !  
Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.