

Pin assignment

Pin assignment number: 1176

Index: A + 2626 = K193

26.07.2011

Connector name: 9-pol.CONTACT Pin-count: 9

Page: 1/1

| Pin | Designation | Description | Level | Driver | NC | Color |
|-----|-------------------|------------------------------|----------------|--------|----|--------|
| 1 | SSI_Clock+_IN | Clock input + | RS 422 | RS 422 | | white |
| 2 | Supply Voltage IN | Supply voltage | 11-27V | | | brown |
| 3 | Supply Voltage IN | Supply voltage | 11-27V | | | green |
| 4 | SSI_DATA+_OUT | Data output + | RS 422 | RS 422 | | yellow |
| 5 | SSI_DATA-_OUT | Data output - | RS 422 | RS 422 | | gray |
| 6 | Ground IN | Ground | 0V | | | pink |
| 7 | Ground IN | Ground | 0V | | | blue |
| 8 | SSI_Clock-_IN | Clock input - | RS 422 | RS 422 | | red |
| 9 | Direction IN | Change of counting direction | Supply Voltage | | 0 | black |

WARNING !!

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.

Pin assignment

Pin assignment number: 2626

Index: + 1176A = K193

26.07.2011

Connector name: 9-pol.CONTACT Pin-count: 9

Page: 1/1

| Pin | Designation | Description | Level | Driver | NC | Color |
|-----|-------------------|------------------------------|----------------|--------|----|--------|
| 1 | SSI_Clock+_IN | Clock input + | RS 422 | RS 422 | | white |
| 2 | Supply Voltage IN | Supply voltage | 11-27V | | | brown |
| 3 | Supply Voltage IN | Supply voltage | 11-27V | | | green |
| 4 | SSI_DATA+_OUT | Data output + | RS 422 | RS 422 | | yellow |
| 5 | SSI_DATA-_OUT | Data output - | RS 422 | RS 422 | | gray |
| 6 | Ground IN | Ground | 0V | | | pink |
| 7 | Ground IN | Ground | 0V | | | blue |
| 8 | SSI_Clock-_IN | Clock input - | RS 422 | RS 422 | | red |
| 9 | Direction IN | Change of counting direction | Supply Voltage | | 0 | black |

WARNING !!

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.