

Pin assignment

Pin assignment number: 1858

Index: + 2960 = K223

30.08.2011

Connector name: 12-pol.CONTACT Pin-count: 12

Page: 1/1

| Pin | Designation | Description | Level | Driver | NC | Color |
|-----|-------------------|----------------------------|-------|--------|----|--------|
| 1 | CH_A_OUT | Channel A | 5V | RS 422 | | yellow |
| 2 | /CH_A_OUT | Channel A inverted | 5V | RS 422 | | violet |
| 3 | not connected | | | | | |
| 4 | CH_B_OUT | Channel B | 5V | RS 422 | | pink |
| 5 | /CH_B_OUT | Channel B inverted | 5V | RS 422 | | white |
| 6 | not connected | | | | | |
| 7 | CH_I_OUT | Channel Reference | 5V | RS 422 | | green |
| 8 | /CH_I_OUT | Channel Reference inverted | 5V | RS 422 | | brown |
| 9 | not connected | | | | | |
| 10 | not connected | | | | | |
| 11 | Supply Voltage IN | Supply voltage | 5V | | | red |
| 12 | Ground IN | Ground | 0V | | | blue |

WARNING !!

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.

Pin assignment

Pin assignment number: 2960

Index: + 1858 = K223

30.08.2011

Connector name: 12-pol.CONTACT Pin-count: 12

Page: 1/1

| Pin | Designation | Description | Level | Driver | NC | Color |
|-----|-------------------|----------------------------|-------|--------|----|--------|
| 1 | CH_A_OUT | Channel A | 5V | RS 422 | | yellow |
| 2 | /CH_A_OUT | Channel A inverted | 5V | RS 422 | | violet |
| 3 | not connected | | | | | |
| 4 | CH_B_OUT | Channel B | 5V | RS 422 | | pink |
| 5 | /CH_B_OUT | Channel B inverted | 5V | RS 422 | | white |
| 6 | not connected | | | | | |
| 7 | CH_I_OUT | Channel Reference | 5V | RS 422 | | green |
| 8 | /CH_I_OUT | Channel Reference inverted | 5V | RS 422 | | brown |
| 9 | not connected | | | | | |
| 10 | not connected | | | | | |
| 11 | Supply Voltage IN | Supply voltage | 5V | | | red |
| 12 | Ground IN | Ground | 0V | | | blue |

Connector coding**'!!! Connector Y - coded !!!****WARNING !!**

,

'De-energize the system before carrying out wiring work or opening and closing electrical connections !!!

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen !!! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.

,