

Pin assignment

Pin assignment number: 10240

Connector name: 25-pol SUB-D

+ 246 = k432

Index:

Pin-count: 25

17.02.2014

Page: 1/1

| Pin | Designation | Description | Level | Driver | NC | Colour |
|-----|-------------------|----------------|----------------|--------|----|--------------|
| 1 | O_D0 | Data output | | | | white |
| 2 | O_D1 | Data output | | | | brown |
| 3 | O_D2 | Data output | | | | green |
| 4 | O_D3 | Data output | | | | yellow |
| 5 | O_D4 | Data output | | | | gray |
| 6 | O_D5 | Data output | | | | pink |
| 7 | O_D6 | Data output | | | | blue |
| 8 | O_D7 | Data output | | | | red |
| 9 | O_D8 | Data output | | | | black |
| 10 | O_D9 | Data output | | | | violet |
| 11 | O_D10 | Data output | | | | gray/pink |
| 12 | O_D11 | Data output | | | | red/blue |
| 13 | O_D12 | Data output | | | | white/green |
| 14 | O_D13 | Data output | | | | brown/green |
| 15 | O_D14 | Data output | | | | white/yellow |
| 16 | O_D15 | Data output | | | | yellow/brown |
| 17 | Strobe_OUT | Strobe | | | | white/gray |
| 18 | not connected | | | | | |
| 19 | not connected | | | | | |
| 20 | not connected | | | | | |
| 21 | I_Latch | High=Latch | Supply Voltage | | 0 | white/blue |
| 22 | Preset1_IN | Preset value 1 | Supply Voltage | | 0 | brown/blue |
| 23 | not connected | | | | | |
| 24 | Supply Voltage IN | Supply voltage | 11-27V | | | brown/red |
| 25 | Ground IN | Ground | 0V | | | white/black |

WARNING

'De-energize the system before carrying out wiring work or opening and closing electrical connections !

Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.

Pin assignment

Pin assignment number: 246 + 10240 = K432
 Connector name: 15-pol SUB-D

Index:
 Pin-count: 15

27.01.2014
 Page: 1/1

| Pin | Designation | Description | Level | Driver | NC | Colour |
|-----|---------------------|----------------------------------|--------|--------|----|--------------|
| 1 | Ser.Program-_IN/OUT | Ser. programming interface RS485 | RS 485 | RS 485 | | white |
| 2 | Ser.Program+_IN/OUT | Ser. programming interface RS485 | RS 485 | RS 485 | | brown |
| 3 | not connected | | | | | |
| 4 | not connected | | | | | |
| 5 | not connected | | | | | |
| 6 | not connected | | | | | |
| 7 | not connected | | | | | |
| 8 | not connected | | | | | |
| 9 | not connected | | | | | |
| 10 | not connected | | | | | |
| 11 | not connected | | | | | |
| 12 | not connected | | | | | |
| 13 | not connected | | | | | |
| 14 | Supply Voltage IN | Supply voltage | 11-27V | | | brown/green |
| 15 | Ground IN | Ground | 0V | | | white/yellow |

WARNING

'De-energize the system before carrying out wiring work or opening and closing electrical connections !
 Short-circuits, voltage peaks, etc. can cause operating failures and uncontrolled operating states, as well as serious personal injuries and damage to property.

Verdrahtungsarbeiten, Öffnen und Schließen von elektrischen Verbindungen nur im spannungslosen Zustand durchführen ! Kurzschlüsse, Spannungsspitzen etc. können zur Fehlfunktion und unkontrollierten Zuständen der Anlage bzw. zu erheblichen Personen- und Sachschäden führen.